

UP TO 30% MORE HORSEPOWER 10-20% FUEL SAVINGS


#### CUMMINS 6.7L TIER III ENGINES

#### CU5703 MODULE INSTALLATION GUIDE Bluetooth

CONNECT

AGDIESELSOLUTIONS.COM

You Tube 🕇




1) Locate the 3 sets of stock injector connectors located on the side of the engine head. These are located on the same side of the engine as the air intake. One connector is located closer to the flywheel-side of the engine, one is in the middle behind the air intake, and the last connector is located closer to the Fan-side of the engine.

Injector connector location. Fan-side of engine. Injector connector location. Middle of engine. Injector connector location. Flywheelside of engine.




**2)** Disconnect all 3 sets of stock injector connectors. Press the release tab on the connector and gently pull the connector apart.



**3)** Route the module harness as shown in the picture below. The module case will be located closer to the flywheel side of the engine.


Note: Refer to the diagram on page 2 for the layout of the harness connections.




**4)** On the Ag Diesel Solutions harness, the male injector connector located closest to the module case will connect to the female injector connector wiring located closest to the flywheel-side of the engine.




**5)** On the Ag Diesel Solutions harness, the male injector connector located closest to the module case will connect to the female injector connector located closest to the flywheel-side of the engine.




6) Continue to the next 2 sets of injector plugs. Repeat Steps 4 and 5 to connect each pair of injector plugs. Note: The new harness will connect in series between the stock injector plugs and stock wiring plugs. All plugs on the new harness will be connected.



**7)** Locate the stock MAP Sensor and disconnect. This is a 4-Pin connector located next to the air intake inlet.



**8)** Connect the new female MAP sensor connector into the stock male MAP sensor. Connect the new male MAP sensor connector into the stock Female MAP sensor wiring.



**9)** Connect the red wire with a ring terminal to a +12V constant source (i.e. battery or alternator.) Connect the black wire with ring terminal to a good chassis ground.



**10)** Plug the Harness into the module. Mount the module with supplied zip ties away from any excessive heat or moving parts. Note: Zip tie the module to the factory wire harness. Mounting the module with the connector down will help prevent moisture from collecting into the module connector





# For any questions on this installation please call Tech Support at 812.618.9168





### SOLUTIONS FARM SMART. FARM EFFICIENT. Why Ag Diesel Solutions Modules ? \_\_\_\_\_

Saving More Fuel Per Hour with 10-20% Returns Getting More Done -- Up to 30% More Horsepower and Torque

No Programming of the Factory ECM or Changes to Fuel Pressure

Linear Based Log d Technology - Only Giving Power when You Need It

Peace of Mind with USA Based Tech Support and a 30 Day Money Back Guarantee

No Loss of Product Benefits if Factory Tuning is Required Reduce Downtime - Install Yourself - No Tech Needed

Transferable to New Machines with Same Engine Does Not Defeat or Delete Any Engine Components

Quality Manufacturing to Withstand a LIFETIME on the Farm



Engineered, Manufactured, Tested and Proven in the

# THIS IS A HIGH PERFORMANCE PRODUCT. USE AT YOUR OWN RISK.

Do not use this product until you have carefully read the following agreement. This sets forth the terms and conditions for the use of this product. The installation of this product indicates that the BUYER has read and understands this agreement and accepts its terms and conditions

# DISCLAIMER OF WARRANTY AND LIMITATION OF LIABILITY

PSI Power, Inc and its successors, distributors, jobbers, and dealers (hereafter "SELLER") shall in no way be responsible for the product's proper use and service. It is the installer's responsibility to check for proper installation and if in doubt, contact the manufacturer. The SELLER assumes no liability regarding the improper installation or misapplication of its products. BUYER ACKNOWLEDGES IT HAS HAD THE OPPORTUNITY TO FULLY INSPECT THE PRODUCT. ACCORDINGLY, BUYER ACKNOWLEDGES THAT THE PRODUCT IS BEING SOLD IN "AS IS/WHERE IS" CONDITION AND WITH ALL FAULTS. EXCEPT AS OTHERWISE PROVIDED HEREIN. THERE ARE NO EXPRESS WARRANTIES WITH RESPECT TO THE GOODS, AND ALL IMPLIED WARRANTIES. INCLUDING BUT NOT LIMITED TO, IMPLIED WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY ARE LIKEWISE HEREBY EXPRESSLY AND FULLY DISCLAIMED. SELLER SHALL NOT BE HELD LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WITH RESPECT TO THE PRODUCTS (INCLUDING, WITHOUT LIMITATION, LOST PROFITS, LOST SALES, LOSS OF PRODUCTION, PROPERTY DAMAGE, PERSONAL INJURY OR LOSS OR DAMAGE RESULTING FROM INTERRUPTION OR FAILURE IN OPERATION OF THE PRODUCTS) AND BUYER HEREBY EXPRESSLY WAIVES AND DISCLAIMS ALL SUCH LIABILITY CLAIMS. THE BUYER ACKNOWLEDGES AND AGREES THAT THE DISCLAIMER OF LIABILITY CONTAINED HEREIN IS A MATERIAL TERM OF THE SALE OF THE PRODUCT AND, TO THE FULLEST EXTENT PERMITTED BY LAW, BUYER SHALL DEFEND, INDEMNIFY AND HOLD SELLER HARMLESS FROM ANY AND ALL CLAIMS, DEMANDS, CAUSES OF ACTION, CONTROVERSIES, LIABILITIES, FINES, LOSSES, COSTS AND EXPENSES (INCLUD-ING, BUT NOT LIMITED TO ATTORNEYS' FEES, EXPERT WITNESS EXPENSES AND LITIGA-TION EXPENSES) ARISING FROM OR RELATED TO SELLER'S PRODUCTS.

#### LIMITED 3 YEAR WARRANTY

PSI Power, INC. (hereafter "SELLER") warrants that the product supplied shall conform to SELLER's specifications and shall be free from defects in design, material or workmanship for 3 years to the original BUYER. This warranty shall not be extended, transferred, assigned or varied except by a written instrument signed by SELLER and BUYER. Products that have been returned to SELLER during the warranty period and accompanied by a dated proof of purchase receipt, with shipping and handling paid by the BUYER, and found to be defective in design, material, or workmanship, in SELLER's sole discretion, may be repaired or replaced at SELLER's option and cost. All warranty claims hereunder are subject to approval by SELLER upon examination of the product. If the product is found not to be defective by SELLER, the product may be returned to BUYER at BUYERS cost. Under no circumstances shall the SELLER be liable for any labor charged or travel time incurred in diagnosis for defects, removal, or reinstallation of this product or any other expenses. This warranty is void on any products that show evidence of misapplication, negligence, improper installation, abuse, lack of proper maintenance or alteration from its original design.

IN THE EVENT THAT THE BUYER DOES NOT AGREE WITH THIS AGREEMENT, THE BUYER MAY PROMPTLY RETURN THIS PRODUCT, IN A NEW AND UNUSED CONDITION, IN THE ORIGINAL PACKAGING, WITH A DATED PROOF OF PURCHASE, TO THE PLACE OF PURCHASE WITHIN (30) DAYS FROM THE DATE OF PURCHASE FOR A FULL REFUND. THE INSTALLATION OF THIS PRODUCT INDICATES THAT THE BUYER HAS READ AND UNDER-STANDS THIS AGREEMENT AND ACCEPTS ITS TERMS AND CONDITIONS

Effective 11/1/2022



UP TO 30% HORSEPOWER INCREASE

- UP TO 10%-20% IN FUEL SAVINGS
- DOES NOT FLASH THE FACTORY ECM
- FIELD TESTED & DYNO PROVEN
- PLUG & PLAY INSTALLATION

Performance Electronics for Agriculture, Forestry, Construction, Pick-Up Trucks, Medium Duty Trucks, RVs, Heavy Duty Semis , and more!



LEARN MORE: AGDIESELSOLUTIONS.COM

You Tube